

CRANBROOK LOOM BEATER WEIGHT

INSTALLATION INSTRUCTIONS

PARTS

1 – Beater weight
#12 x 1 ¼" Phillips flat head screws

TOOLS

Drill with 3/16" drill bit
Phillips screwdriver

ASSEMBLY

1. Remove the beater assembly from the loom.
2. Center the beater weight on the back side of the beater race and mark the position of the holes.
3. Drill pilot holes with 3/16" bit, approximately 1 ¼" deep.
4. Secure the beater weight on the back of the beater race with the #12 x 1 ¼" Phillips screws.
5. Place the beater assembly back onto the loom.



Find out more at schachtspindle.com
Schacht Spindle Company 6101 Ben Place Boulder, CO 80301
p. 303.442.3212 f. 303.447.9273

© 2013 Schacht Spindle Company, Inc.