

WOLF TRAP

ASSEMBLY INSTRUCTIONS FOR ALL WOLF LOOMS

FL3830
FL3830C
FL3831
FL3831C
FL3832
FL3832C



PARTS

- 1 – left side bracket
- 1 – right side bracket
- 1 – cloth sleeve
- 2 – ½" dowels
- 4 – 6-18 x 1-¼" Phillips flat head sheet metal screws

TOOLS

- #2 Phillips screwdriver

ASSEMBLY

1. Slide the dowels into the casings on the long sides of the cloth sleeve.
2. Line up the side brackets with the large holes facing to the inside.
3. Fit the dowels into the holes in the side brackets. From the outside of the bracket, secure the dowels with the Phillips screws.
4. Place the assembled Wolf Trap onto the front beam of your loom.



Find out more at schachtspindle.com
Schacht Spindle Company 6101 Ben Place Boulder, CO 80301
p. 303.442.3212 f. 303.447.9273
© 2018 Schacht Spindle Company, Inc.

WOLF TRAP

ASSEMBLY INSTRUCTIONS FOR ALL WOLF LOOMS

FL3830
FL3830C
FL3831
FL3831C
FL3832
FL3832C



PARTS

- 1 – left side bracket
- 1 – right side bracket
- 1 – cloth sleeve
- 2 – ½" dowels
- 4 – 6-18 x 1-¼" Phillips flat head sheet metal screws

TOOLS

- #2 Phillips screwdriver

ASSEMBLY

1. Slide the dowels into the casings on the long sides of the cloth sleeve.
2. Line up the side brackets with the large holes facing to the inside.
3. Fit the dowels into the holes in the side brackets. From the outside of the bracket, secure the dowels with the Phillips screws.
4. Place the assembled Wolf Trap onto the front beam of your loom.



Find out more at schachtspindle.com
Schacht Spindle Company 6101 Ben Place Boulder, CO 80301
p. 303.442.3212 f. 303.447.9273
© 2018 Schacht Spindle Company, Inc.