

MATCHLESS SPINNING WHEEL

NYLON TREADLE HINGE REPLACEMENT

PARTS

Nylon hinge

TOOLS

Phillips screwdriver

Pencil

REPLACE THE HINGE

1. Soak the new hinge in hot water to make it more flexible.
2. Place the wheel on its back. Using a pencil, outline the hinge to be removed.
3. Remove the screws holding the old hinge on the bottom of the treadle. Save the screws for reuse.
4. Align the new hinge in the outline and attach using the screws from the previous step.
5. Repeat steps 1-4 for any additional hinges.
6. Place the wheel on the floor. Align the hinges on the metal treadle bar and push down on the treadles until the bar snaps into the hinges.



Find out more at schachtspindle.com

Schacht Spindle Company 6101 Ben Place Boulder, CO 80301

p. 303.442.3212 f. 303.447.9273

© 2012 Schacht Spindle Company, Inc.

08.12